



SERVICE MANUAL SUPPLEMENT-QUICK SERVICE GUIDE FOR M-SERIES AND RG-SERIES PRODUCTS

ICON — Atmospheric Vent Water Heaters

ERROR CODE	DEFINITION	SERVICE ACTION	POSSIBLE PARTS NEEDED
No LED	No pilot light / heater not in operation	Follow lighting instructions on the water heater	1) None
One flash and three second pause	Knob in pilot position or thermostat satisfied	None	1) None
LED Strobe (two quick flashes) and three second pause	Thermostat calling for heat	None	1) None
LED on continuously	Control knob turned to the off position	Wait for LED to go off before relighting	1) None
Two flashes and three second pause	Weak pilot signal detected	Verify pilot is lit Check thermopile voltage output Check wire connections at gas valve	1) Pilot assembly 2) Gas valve
Three flashes and three second pause	Gas valve has not seen temp rise in proper amount of time	Check temp probe ohms Verify water is not flowing	1) Gas valve cover w/ temp probe
Four flashes and three second pause	High tank temperature	Check temp probe ohms Check water temperature	1) Gas valve cover w/ temp probe
Five flashes and three second pause	Thermostat sensor fault	Check temp probe ohms Check water temperature	1) Gas valve cover w/ temp probe
Six flashes and three second pause	Water leak detected by the accessory module (if installed)	Refer to troubleshooting for the accessory module	1) Refer to troubleshooting for the accessory module
Seven flashes and three second pause	Gas valve fault	Reset gas valve. If problem persists, replace gas valve	1) Gas valve
Eight flashes and three second pause	Pilot remains lit while the control knob is in off position	Check gas pressure Replace gas valve	1) Gas valve 2) Gas valve cover w/ temp probe

NOTE:

- Check all wire connections**
- Check gas inlet and manifold gas pressure**
- Check for grounding connections**

Technical Support
800-334-3393